

INSTRUCTION MANUAL

Elite Series

*Capacitive
Sensor
Systems*

CPL190 • CPL290 • CPL490 • MM190 • TMP190 • EN190

LION
PRECISION

Table of Contents

Approvals and Safety Considerations	3
Probe Tip Contact Caution	3
Helpful Technical Support Documents Online	3
CPL190/290 Sub-Nanometer Capacitive Displacement Sensor	4
Overview of Front Panel Controls, Indicators, and Connectors	5
Multiple Channel Measurements	5
CPL190/290 Specifications	6
CPL490 Wide Bandwidth Picometer Capacitive Displacement Sensor	7
Overview of Front Panel Controls, Indicators, and Connectors	8
Multiple Channel Measurements	8
CPL490 Specifications	9
Changing CPL190/290/490 Bandwidth Settings	10
MM190 Meter and Function Module	11
MM190 Specifications	12
TMP190 Temperature Sensing and Encoder/Index Input Module	13
TMP190 Temperature Specifications ¹	14
Encoder/Index Pulse Input	15
Elite Series Enclosures	17
Power Specifications	17
EN191, EN192, EN193 Power Connector	18
External Power Supply	18
DAQ Connector Pinout	19
Mechanical Specifications: EN191, EN192, EN193	20
Mechanical Specifications: EN196, EN198	21
Accessories	22
Air-Bearing C-LVDT: Capacitive LVDT-Type Contact Sensor	22

Approvals and Safety Considerations

The Elite Series is compliant with the following CE standards:

Safety: EN 61010-1:2010



EMC: IEC 61326-1:2013, IEC 61326-2-3:2013

To maintain compliance with these standards, the following operating conditions must be maintained:

- All I/O connecting cables must be shielded and less than three meters in length
- AC power cables must be rated at a minimum of 250 V and 5 A
- AC power must be connected to a grounded mains outlet rated less than 20A
- Use the included CE approved power supply with 1-, 2-, and 3- slot enclosures. If an alternative power supply is used, it must have equivalent CE certification and provide safety isolation from the mains according to IEC60950 or 61010.
- Sensors must not be attached to parts operating at hazardous voltages in excess of 33VRMS or 70VDC

Use of the equipment in any other manner may impair its safety and EMI protections.

Probe Tip Contact Caution

The sensing tips of capacitive probes produce voltages as high as 70 Vrms. These are high frequency voltages with very low power so they pose no danger. Normally when the probe tip is touched, the probe stops functioning and voltage is reduced to near zero. But under certain circumstances, the voltage may cause a slight tingle or burning sensation, especially with the second generation probes used with the CPL490. For maximum performance probe tips should remain free of oils or other contaminants.

For these reasons, it is recommended the probe tips not be touched.

Helpful Technical Support Documents Online

Lion Precision's web site has a large selection of technical documents (TechNotes and Application Notes) in the Technical Library. These documents provide detailed descriptions of the operation and use of Lion Precision high-performance sensors.

The Technical Library can be accessed at:

www.lionprecision.com/tech-library

Some of the titles include:

Understanding Sensor Resolution Specifications and Effects on Performance

Capacitive Sensor Theory of Operation

Error Sources: Probe/Target Angle

Capacitive Sensors in Vacuum

Capacitive Sensor Phasing and Ungrounded Targets

Capacitive Probe Cabling Considerations

Elite Series Phase/Amplitude Frequency Response

Z-Height Measurement with Capacitive and Eddy-Current Sensors

Thickness Measurement with Capacitive Sensors

Glue Sensing with Capacitive Sensors

CPL190/290 Sub-Nanometer Capacitive Displacement Sensor

The CPL190/290 Capacitive Sensor is a precision, noncontact measurement device. The output voltage changes in direct linear proportion to changes in the gap between the probe and the target. The sensor is normally used to measure conductive targets, but it can also be used with nonconductive targets under the right conditions. For more information about measuring nonconductors, visit the Technical Library at www.lionprecision.com or call for assistance.


The CPL190/290 works with most Standard Probes.

Basic Operation

The output voltage is accessed via the front panel BNC connector, or by a data acquisition system via the high-density connector on the rear of the enclosure. This connector can connect directly to National Instruments™ data acquisition products. See the enclosure section of this manual for specifics on the system DAQ connector (page 19).

As the gap between the probe and target changes, the output voltage will change accordingly. As the probe approaches the target, the output voltage will become more positive.

Note: Calibrated Range “Near” and “Far” lights (red) indicate that the probe is out of its calibrated range and the output is not guaranteed to be accurate even though the voltage may be in range and continue to change.



Probes are calibrated to specific modules. With multiple channel systems, be sure the number on the probe cable (near the connector) matches the number on the module handle.

The CPL290 provides low and high sensitivity calibrations for a single probe. Use the Sensitivity switch to select the desired sensitivity. Calibration detail is provided on calibration sheets shipped with the product.

Noncontact sensors normally measure changes from a reference position.

Making a basic measurement

1. Connect probe to module
2. Set the target to a reference position or condition
3. Mount probe near target
4. Adjust the probe position until the “Calibrated Range” indicator is at center position
5. Use the Zero adjustments to adjust the output voltage to zero (optional)
6. As the probe/target gap changes, the output voltage will change accordingly

Interpreting the output voltage

The amount of change of the output voltage for a given change in the probe/target gap is called *Sensitivity*. The sensitivity of the sensor is listed on the calibration sheets which arrived with the sensor.

Change in gap calculation:

$$\text{Gap Change} = \text{Voltage Change} / \text{Sensitivity}$$

For example: With a sensitivity of 1 V/2 μm and a voltage change of 3 V, the gap change would be 6 μm (3/0.5).

Overview of Front Panel Controls, Indicators, and Connectors

Zero Adjust

Adjusts the analog output voltage after the probe is initially positioned. Typically, the analog output voltage is adjusted to zero volts at range center. There is a coarse adjustment (± 10 VDC), the outer control, and a fine adjustment (± 1 VDC), the inner control. When the Zero switch is in the off position, the zero adjustment has no effect.

Sensitivity (CPL290 Only)

The CPL290 provides a high-sensitivity and a low-sensitivity calibration for one probe. Refer to the calibration sheets for specific calibration information. Select the desired sensitivity with this switch.

Switching sensitivities will usually require repositioning the probe.

Calibrated Range Indicator

Green LEDs indicate that the probe is in its calibrated range and the output voltage is an accurate representation of the target position. Red LEDs indicate that the probe is out of range and the output voltage is not valid.

The Calibrated Range Indicator is not affected by the Zero adjustment. The module is factory calibrated to zero volts at range center, however, it is possible to adjust the output voltage to zero while the probe is positioned toward the end of the calibrated range. In this situation, the probe can go out of its calibrated range while the output voltage continues to appear valid. The output voltage may continue to change, but the output is no longer guaranteed to be accurate. In this condition, the output voltage may appear valid but the Calibrated Range Indicator will be red. Out-of-Range indicator signals available through the system DAQ connector are activated anytime the Calibrated Range Indicator is red.

Analog Output

Provides connection to the analog output voltage, which is proportional to the distance between the probe and the surface of the material being measured. A typical output voltage range is ± 10 VDC. The specific ranges are listed on the accompanying calibration sheets.

The analog output provided on the data acquisition (DAQ) connector on the rear of the enclosure is differential. See the enclosure section of this manual for specifics on the system DAQ connector (page 19).

Ground


A banana-plug cable can be connected here for grounding the target. In most cases, separate grounding of the target is not necessary. If the target is not grounded through another path, and the output exhibits excessive electrical noise, grounding the target may reduce the output noise. When low-noise operation is critical, separate grounding is recommended even if the target is well grounded through another path.

Probe Connector

Connect the probe by aligning the red dots on the connectors and inserting the probe connector.

To disconnect the probe, pull on the knurled barrel of the probe connector to release it.

DO NOT PULL ON THE CABLE.



Multiple Channel Measurements

Using multiple sensors on the same target requires that the sensor excitation voltages be synchronized. This is done automatically by the Elite Series enclosures. In addition, even and odd channel numbers use inverted (180°) excitation

voltages. This eliminates offset and scale errors that may otherwise occur with poorly grounded targets such as semiconductors. For details on use with ungrounded targets and the advantage of inverted excitation voltages, refer to Lion Precision TechNote *LT03-0022 Capacitive Sensors and Ungrounded Targets*, available at www.lionprecision.com; click on Technical Library.

CPL190/290 Specifications¹

Linearity Error	±0.2% F. S. or better, dependent on calibration
Error Band	±0.3% F. S. or better, dependent on calibration
Standard Bandwidth (-3 db)	15 kHz -10%+30%
Coarse Zero Adjustment Range	±10 VDC
Fine Zero Adjustment Range	±1 VDC
Meets ANSI/ASME B5.54 Standard	Yes
Probe Interchangeability	Typical sensitivity variation for same probe model: 10%
Operating Temperature	4°-50°C
Thermal Stability	0.02% F.S./°F, 0.04% F.S./°C
Typical Oscillator Frequency	Probe cable < 12 feet: 1 MHz Probe cable > 12 feet: 500 kHz
Output Impedance	0 Ω
Output Max Voltage	±13.5 VDC
Output Max Current	10 mA

¹ These specifications are typical for standard components and calibrations. Customizations can effect performance. Check the calibration sheet shipped with the product for specific details on your system. In high EMI environments (10 V/m), output noise may rise to 0.2 VRMS (1% resolution) and DC output may shift.

CPL490 Wide Bandwidth Picometer Capacitive Displacement Sensor


The CPL490 Capacitive Sensor is a very high precision, noncontact measurement device. The output voltage changes in linear proportion to changes in the gap between the probe and the target. The sensor is normally used to measure conductive targets, but it can also be used with nonconductive targets in some applications. For more information about measuring nonconductors, visit the Technical Library at www.lionprecision.com or call for assistance.

The CPL490 only works with 2nd Generation Probes which include integral electronics.

Basic Operation

The output voltage is accessed via the front panel BNC connector, or by a data acquisition system via the high-density connector on the rear of the enclosure. This connector can connect directly to many National Instruments™ data acquisition products. See the enclosure section of this manual for specifics on the system DAQ connector (page 19).

As the gap between the probe and target changes, the output voltage will change accordingly. As the probe approaches the target, the output voltage will become more positive.



Note: “Near” and “Far” lights (red) indicate that the probe is out of its calibrated range and the output is not guaranteed to be accurate even though the voltage may continue to change.

Probes are calibrated to specific modules. With multiple channel systems, be sure the number on the probe cable (near the connector) matches the number on the module handle. Calibration detail is provided on calibration sheets shipped with the product.

Noncontact sensors normally measure changes from a reference position.

Making a basic measurement

1. Connect probe to module
2. Set the target to a reference position or condition
3. Mount probe near target (probes should be mounted by the 8 mm diameter probe body which extends from the larger probe electronics housing)
4. Adjust the probe position until the Near/Far indicator is at center position
5. Use the Zero adjustments to adjust the output voltage to zero (optional)
6. As the probe/target gap changes, the output voltage will change accordingly

Interpreting the output voltage

The amount of change of the output voltage for a given change in the probe/target gap is called *Sensitivity*. The sensitivity of the sensor is listed on the calibration sheets which arrived with the sensor.

Change in gap calculation:

$$\text{Gap Change} = \text{Voltage Change} / \text{Sensitivity}$$

For example: A sensitivity of 1 V/2 μm and a voltage change of 3 V, the gap change would be 6 μm (3/0.5).

Overview of Front Panel Controls, Indicators, and Connectors

Zero Adjust

Provides a DC shift of the analog output voltage after the probe is initially positioned. The adjustment has a range of ± 1 VDC. Typically, the analog output voltage is adjusted to zero volts at range center. When the Zero switch is in the off position, the zero adjustment has no effect.

Calibrated Range Indicator (Near Far)

Indicates where the probe is within its calibrated range. Green LEDs indicate that the probe is in its calibrated range and the output voltage is an accurate representation of the target position. Red LEDs indicate that the probe is out of range. When the probe is out of range, the output voltage may not be an accurate indication of the target position even if it is still within the ± 10 VDC range. The Zero adjust has no effect on the Calibrated Range Indicator.

Analog Output

Provides connection to the analog output voltage, which is linearly proportional to the distance between the probe and the surface of the object being measured. A typical output voltage range is ± 10 VDC. The specific range is listed on the calibration sheet shipped with the device.

The analog output provided on the data acquisition (DAQ) connector on the rear of the enclosure is differential. See the enclosure section of this manual for specifics on the system DAQ connector (page 19).

Ground


A banana-plug cable can be connected here for grounding the target. In most cases, separate grounding of the target is not necessary. If the target is not grounded through another path, and the output exhibits excessive electrical noise, grounding the target may reduce the output noise. When low-noise operation is critical, separate grounding is recommended even if the target is well grounded through another path.

Probe Connector

Connect the probe by aligning the red dots on the connectors and inserting the probe connector.

To disconnect the probe, pull on the knurled barrel of the probe connector to release it.

DO NOT PULL ON THE CABLE.



Multiple Channel Measurements

Using multiple sensors on the same target requires that the sensor excitation voltages be appropriately selected. Systems ordered for multiple channel use on the same target will be specially calibrated to avoid inter-channel interference. Using multiple CPL490s together which are not so calibrated may produce interference in the output voltages of all channels. Sensors that will be used together to measure the same object must be ordered together so they can be appropriately calibrated. Using multiple sensors not so calibrated may not provide accurate results.

CPL490 Specifications¹

Linearity Error	0.2% F.S.
Error Band	0.3% F.S.
Bandwidth (-3 db)	Selectable: 1 kHz, 10 kHz, 15 kHz, 50 kHz Bandwidths are -10%+30%
Meets ANSI/ASME B5.54 Standard	Yes
Operating Temperature	15-40 °C
Thermal Stability	0.02-0.04% F.S., Probe/Range dependent
Oscillator Frequency	Probe/Calibration dependent. 6.4 MHz typical.
Output Impedance	0 Ω
Output Max Voltage	± 13.5 VDC
Output Max Current	10 mA

¹ These specifications are typical for standard components and calibrations. Customizations can affect performance. Check the calibration sheet shipped with the product for specific details on your system.
In high EMI environments (10 V/m), output noise may rise to 0.5 VRMS and DC value may shift 0.7 VDC.

Changing CPL190/290/490 Bandwidth Settings



The CPL190/290/490 provides a two-position DIP switch for setting bandwidth.

When changing bandwidth, change all modules in the system. Bandwidth is a system-wide setting; bandwidth switches on the modules within a system are interconnected. ***All of the bandwidth switches must be in the same position for predictable results.***

This switch is located as shown in the drawings at the right. The following table shows the bandwidths available and their associated dip switch settings.


Bandwidths listed are approximate. Actual values depend on the probe and calibration.

CPL190/290 (S2)	CPL490 (S1)	2	1	Notes
15 kHz	50 kHz	OFF	OFF	Computer control of bandwidth requires this setting (OFF, OFF)
10 kHz	15 kHz	OFF	ON	
1 kHz	10 kHz	ON	OFF	
100 Hz	1 kHz	ON	ON	



Bandwidth DIP Switch Access

Be careful to only change switches and jumpers as directed in this manual. Any other changes will affect the calibration of the module.



MM190 Meter and Function Module

The MM190 Module displays dimensional values derived from sensors within an Elite Series system. Any two channels can be summed and peak capture functions can be performed on an individual channel or a resulting sum. The displayed value is also provided as an analog voltage via a front panel BNC connector.

Capabilities

- Displays dimensional units derived from sensor output voltages
- Selectable input channels
- Sum and Difference of any two channels
- Peak capture functions
- Metric/Inch unit selection
- Analog voltage output proportional to displayed value

Setup

Pressing the appropriate button repeatedly rotates through selections.

1. Select sensor channels for A and B
2. Select individual channel to be displayed (A or B) or the sum or difference of A and B
3. Select a peak function
4. Select metric or inch units

Display Units


The MM190 measures the analog voltage from the selected sensor channel and uses digital signal processing to perform any summing and/or peak capture functions. The result is converted to actual dimensional units for display. The multiplier indicators (milli, micro) combined with the Metric or Inch units indicate the dimensions of the displayed value. The button selects either Metric or Inch units. The multipliers are not selectable; they are selected by the system based on the calibration values of the displayed channel.

Channel Selection

Any existing sensor channel can be selected for A or B.

Summing Options

A and B can be displayed independently or combined as a sum or a difference.



Peaks

Five options are available:

NONE – Display is real-time value of input channels.

MAX – Displays the most positive value since the Reset (RST) button was pressed.

MIN – Displays the most negative value since the Reset (RST) button was pressed.

TIR – Displays the maximum difference between the MAX and MIN values since the Reset (RST) button was pressed. TIR is always a positive value.

TRK – Tracking TIR displays the *current* maximum difference between the MAX and MIN values. When the TIR value is reduced, the displayed value will decay to the lower value within approximately one second.

Analog Output (BNC)

The analog voltage output from the MM190 BNC connector is scaled the same as the BNC output voltage from the selected sensor channels. For example, if the sensor channels are scaled at 1 V/1 μm , the MM190 will also scaled at 1 V/1 μm .

When two channels are summed, the MM190 BNC output voltage is divided by two. For example, summing sensor channels at 1 V/ 1 μm each will produce an MM190 output voltage scaled at 0.5 V/1 μm . This allows both sensor channels to operate at full ± 10 V without exceeding the ± 10 V of the MM190.

MM190 Specifications

BNC Output Scaling Error:	-3.0%
Internal Scaling Error:	0.2%
Difference Error:	0.2%
Summing Error:	0.2%
Tracking TIR Error Relative to Frequency: (not recommended below 100Hz)	10 Hz: -15.0% 100 Hz: $\pm 0.3\%$ 1 kHz: $\pm 1.5\%$ 5 kHz: $\pm 4.0\%$
TIR Error Relative to Input Frequency:	DC: -15.0% 1 kHz: $\pm 1.3\%$ 5 kHz: $\pm 4.0\%$
Peak Droop:	1 mV/15 seconds
BNC Output Impedance	150 Ohms

TMP190 Temperature Sensing and Encoder/Index Input Module

The TMP190 Module monitors up to seven channels of temperature data and provides signal conditioning and input connections for encoder and index inputs.

Requirements


The TMP190 is used with the Lion Precision Spindle Error Analyzer (SEA) and requires the SEA software to access the temperature signals.

Operation – Temperature Sensing

Temperature Probes

Thermistor type temperature probes are used with the TMP190 which supports up to seven channels of temperature sensing.

Temperature probes provided with the module use YSI thermistors:
 YSI 44036 Series Thermistor (10 kΩ @ 25° C).




Temperature Probe	
Magnetic Surface Probe. P016-4050	<p>0.25" (6.4mm)</p> <p>10' (3m)</p> <p>0.5" (12.7mm)</p>

Making Temperature Measurements

Place temperature probes in positions to take desired measurements. When measuring surface temperatures, solid mechanical contact is important.


Use Spindle Error Analyzer (SEA) Software to extract temperature readings.

Block Diagram - Temperature



Connections to Temperature Probes

The two wires of each temperature probe are connected according to the chart below. The probes are by nature unpolarized so there is no differentiation between the two conductors.



Pin Numbers	Connection	Pin Numbers	Connection
1, 9	Probe 1 (T1)	5, 13	Probe 5 (T5)
2, 10	Probe 2 (T2)	6, 14	Probe 6 (T6)
3, 11	Probe 3 (T3)	7, 15	Probe 7 (T7)
4, 12	Probe 4 (T4)	8	No connection

TMP190 Temperature Specifications¹

Accuracy	$\pm 1.8\text{ }^{\circ}\text{F}@40\text{ }^{\circ}\text{F} - 180\text{ }^{\circ}\text{F}$	$\pm 1.0\text{ }^{\circ}\text{C}@4\text{ }^{\circ}\text{C} - 82\text{ }^{\circ}\text{C}$
Output Voltage	$\pm 10\text{VDC}$	
Measuring Range	$40\text{ }^{\circ}\text{F} - 180\text{ }^{\circ}\text{F}$	$4\text{ }^{\circ}\text{C} - 82\text{ }^{\circ}\text{C}$
Temperature Probe Interchangeability Error	$\pm 0.2\text{ }^{\circ}\text{F} @ 68\text{ }^{\circ}\text{F}$	$\pm 0.1\text{ }^{\circ}\text{C} @ 20\text{ }^{\circ}\text{C}$

¹Shifts as high as $4\text{ }^{\circ}\text{C}$ may occur in high EMI conditions (10 V/m).

Encoder/Index Pulse Input

The TMP190 also processes encoder and index pulse inputs for use by the Spindle Error Analyzer. The module performs basic signal processing on the incoming signal then passes the conditioned signal to the data acquisition hardware for analysis by the software.

By definition, index pulses occur once during each revolution of the spindle. Encoder pulses occur many times per revolution. Both are used to provide angular location information to software during a measurement of a rotating target.

Encoder and Index LEDs

To help verify encoder and index pulse operation, green LEDs indicate activity on the encoder and index inputs by flashing at half the frequency of the corresponding input signal.

Single-Ended or Differential Inputs

Encoder and index inputs can be configured as single-ended or differential.


In single-ended mode, the signal is measured between the + input and ground. In differential mode, the signal is measured between the + and – inputs.

Differential inputs are less susceptible to noise and interference. Noise and interference from the measurement environment is often injected equally into both wires from the encoder or index generator. When the signal is taken differentially, the noise and interference is canceled resulting in a cleaner signal.

The front panel switch selects the operating mode.

Connections – Encoder/Index


DC power is available on the connector to power encoders or proximity switches.




Pin Number	Signal
1	Ground
2	Ground
3	+5 VDC, 200 mA max. with self-resetting fuse
4	Ground
5	+15 VDC, 10 0mA max. with self-resetting fuse
6	– Index input, ±12 V Max.
7	+ Index input, ±12 V Max.
8	– Encoder input, ±12 V Max.
9	+ Encoder input, ±12 V Max.

Block Diagram – Encoder/Index

Differential Input Configuration





Single-Ended Input Configuration



Detailed datasheet on the 75175 Transceiver is available at:
<http://focus.ti.com/lit/ds/symlink/sn75175.pdf>

Elite Series Enclosures



Elite Series enclosures provide housing and critical signals to Elite Series modules. Sensor output signals are available via a rear-panel high-density connector which is configured for direct connection to National Instruments™ data acquisition hardware.

The specific Elite Series enclosure model number indicates the maximum number of slots available for plug-in modules as well as other features:


Model	Number of module slots	Input power	Tip-up handle	Mounting flanges
EN191	1	±15 VDC	No	Yes
EN192	2	±15 VDC	No	Yes
EN193	3	±15 VDC	No	Yes
EN196	6	100-250 VAC 50/60 Hz	Yes	No
EN198	8	100-250 VAC 50/60 Hz	Yes	No

Power Specifications

Model	Power Input	Notes
EN191, EN192, EN193	±15 VDC ±5%, 400mA Maximum (A power supply is included with orders)	To maintain maximum resolution use a linear power supply or a power supply with switching frequency greater than 100 kHz such as Lion Precision Power Supply P014-5040. To maintain CE compliance, use the included power supply or equivalent CE compliant model.
EN196, EN198	100-250 VAC, 50/60 Hz, 250 VA Maximum	

EN191, EN192, EN193 Power Connector

Pin	Connection
1	Ground
3	-15 VDC
4	+15 VDC




Power Connector
Pin Numbers
On Rear Panel

External Power Supply

EN191, EN192, and EN193 systems include an external power supply. The supply has a connector which allows direct connection to the enclosure.

This supply features a high-frequency (100kHz) switching supply. The high switching frequency allows the sensing modules to operate at maximum resolution.


DC Output Voltage	+15 VDC; 2.0 A -15 VDC; 1.0 A
AC Input Voltage	100-240 VAC, 50/60 Hz, 1.35 A max



DAQ Connector Pinout


All unlisted pins are reserved for proprietary use by Lion Precision and should not be connected to external contacts.

Pin	Output Signals
11	Encoder
12, 13, 15, 18, 53	Digital Ground
29, 32, 64, 67	Analog Ground
23	- Analog Out; Channel 8
25	+ Analog Out; Channel 7
26	- Analog Out; Channel 6
28	+ Analog Out; Channel 5
30	+ Analog Out; Channel 4
31	- Analog Out; Channel 3
33	+ Analog Out; Channel 2
34	- Analog Out; Channel 1
57	+ Analog Out; Channel 8
58	- Analog Out; Channel 7
60	+ Analog Out; Channel 6
61	- Analog Out; Channel 5
63	- Analog Out; Channel 4
65	+ Analog Out; Channel 3
66	- Analog Out; Channel 2
68	+ Analog Out; Channel 1




Mechanical Specifications: EN191, EN192, EN193

Model	A	B	C
EN191	3.33" 84.6 mm	2.606" 66.2 mm	3.806" 96.7 mm
EN192	4.73" 120.1 mm	4.006" 101.8 mm	5.206" 132.2 mm
EN193	6.13" 155.7 mm	5.406" 137.3 mm	6.606" 167.8 mm



Mechanical Specifications: EN196, EN198

Model	A
EN196	10.1" 257 mm
EN198	14.3" 364 mm



Accessories

Air-Bearing C-LVDT: Capacitive LVDT-Type Contact Sensor

The Air-Bearing C-LVDT converts a capacitive sensor using a standard capacitive probe into a high-precision contact displacement sensor similar to an LVDT. The capacitive probe is installed in the top of the C-LVDT body where it measures the location of a target connected on the inside end of the stylus. The C-LVDT uses a linear air-bearing for nearly friction-free movement of the stylus, and the porous carbon air bearing is square to prevent stylus rotation. Adjustable air pressure for extending the stylus provides for contact forces less than one gram, and the C-LVDT features a retraction port through which application of air pressure will retract the stylus.

The C-LVDT uses an interchangeable diamond tip. Diamond has been selected over ruby for the following reasons:

- Low Friction - Side forces cause less lateral deflection from moving targets and less hysteresis on direction reversal.
- Highly Polished Surface - Diamond accepts and holds a high polish, minimizing the possibility of scratching the measured surface.
- Minimal Wear - Increased accuracy and longer life.

Contact Force Adjustment

There is a contact force adjustment screw located on the end of the probe body near the cable exit. Use a 1/16" hex key to turn the adjustment clockwise to increase the contact force or counter clockwise to decrease it. Contact force is also a function of the air pressure applied to the C-LVDT. To maintain constant contact force, supplied air pressure must be held constant.

Air Exhaust

The 0.1" slot around the body near the top of the C-LVDT is where air is exhausted. Do not clamp the C-LVDT over this ring. The ring must remain at least partially clear at all times for proper operation of the C-LVDT.

Specifications

Measurement Range	0.5 mm, 0.020 inch
Contact Force	0.2 g to 100 g
Radial Stiffness	< 0.25 $\mu\text{m/g}$
Bearing	Linear, porous air bearing
Diamond Tip	Radius: 3.175 mm, 0.125 inch Mount: 4-48AGD Thread
Weight of Moving Mass	4.2 g
Air Connection	1/16 inch ID flexible tubing
Air Consumption	3-7 lpm, 0.10-0.25 cfm
Operating Air Pressure	420-480 kPa, 60-70 psi
Air Requirement	Dry, filtered to less than 5 μm particle size

Mechanical Detail

